

# ISR SERIES HITCHES



**SuperLite**

#PR2400 - 20K



**Super 5th**

#PR1900 - 16K  
#PR2100 - 20K  
#PR2200 - 24K



**SuperGlide**

#PR2700 - 16K  
#PR2900 - 20K  
#PR2300 - 24K

**ALL THE BELOW KITS FIT LONG OR SHORT BED TRUCKS WITH ANY ISR HITCH.**

**HD (HEAVY DUTY) KITS ARE RECOMMENDED FOR USE WITH ISR HD #2200 AND #2300 HITCHES**

NOTE: In order to determine the total tow capacity of a system, you must consider the weight ratings of each component in that system. This includes, but may not be limited to, the rating of the tow vehicle, the fifth wheel hitch, and the hitch's mounting system. Actual tow capacity of the system will be equal to the lowest rated component

**UNIVERSAL**

**UNIVERSAL**

**Heavy Duty**

**CUSTOM**

**CUSTOM**

**Heavy Duty**

**SUPERRAIL**

**GM**

2020	2500 & 3500 (NO DRILL)			PR2770		PR2338
2016-2019	2500 & 3500 (NO DRILL) (designed for easier install)			PR2762		
2011-2019	2500 & 3500 (NO DRILL)			PR2724	PR2226	PR2328
2001-2016	2500 & 3500 HD	PR2720				
1999-2010	2500 & 3500 HD			PR2734	PR2224	PR2326
2019-2020	1500 (new body style)			PR2768		
2007-2019	1500 (6-1/2' bed, old body style)	PR2720		PR2730		

**RAM**

2013-2020	3500 (NO DRILL)			PR2742		
2014-2020	2500 (NO DRILL)			PR2746		PR2336
2013	2500 (NO DRILL)			PR2740		
2003-2012	2500 & 3500 (*NO DRILL) (does not fit 3500 w/ overload springs)	PR2720	PR2220	PR2736*	PR2230*	PR2330*
2016-2020	1500 (does not fit w/ air bags)			PR2764		
2009-2015	1500 (does not fit w/ air bags)			PR2728		

**FORD**

2017-2020	F250 & F350 (NO DRILL)			PR2766		PR2332
2011-2016	F250 & F350 (NO DRILL)			PR2738	PR2228	PR2324
1999-2016	F250 & F350	PR2720	PR2220			2324
1999-2010	F250 & F350			PR2726	PR2228	
2015-2020	F150 (NO DRILL)			PR2760		
2004-2014	F150 (NO DRILL)			PR2732		

**TOYOTA**

2007-2019	Tundra (fits all bed lengths)			PR2748		
-----------	-------------------------------	--	--	--------	--	--

**ALL THE ABOVE KITS FIT LONG OR SHORT BED TRUCKS WITH ANY ISR HITCH.**

**HD (HEAVY DUTY) KITS ARE RECOMMENDED FOR USE WITH ISR HD #2200 AND #2300 HITCHES**

**UNIVERSAL KITS include "L" Brackets, ISR Base Rails & Hardware. Heavy Duty kits include ISR HD Base Rails & Hardware**

**CUSTOM KITS include Custom Mounting Brackets, ISR Base Rails, & Hardware. Heavy Duty kits include ISR HD Base Rails, & Hardware**

**SUPERRAIL KITS featuring Clean Bed Technology include totally removable SuperRails & Posts, Mounting Brackets & Hardware for a clean**

# TRADITIONAL SERIES SUPERGLIDE HITCHES



#PR4100 - 16K  
#PR4400 - 20K



#PR3100 - 12K

Universal Mounting Kits only applicable for #PR4100 and #PR4400 SuperGlide models

#PR3100 SuperRail Mounting Kits only applicable to the #PR3100 Traditional Series SuperGlide

**NOTE:** In order to determine the total tow capacity of a system, you must consider the weight ratings of each component in that system. This includes, but may not be limited to, the rating of the tow vehicle, the fifth wheel hitch, and the hitch's mounting system. Actual tow capacity of the system will be equal to the lowest rated component.

UNIVERSAL

SUPERRAIL

#3100 SUPERRAIL

GM				
2011-2019	2500 & 3500 (NO DRILL)		PR4428	
1999-2010	2500 & 3500	PR3340	PR3345	
2007-2019	1500 (6-1/2' bed, old body style)		PR4423	
1999-2007	1500 (6-1/2' bed, except 2007 mid-year body change)	PR3340	PR3345	
2019-2020	1500 (5'8" bed, new body style)			PR3124*
2007-2019	1500 (5'8" bed, old body style)			PR3117*
2004-2007	1500 (5'8" Bed, except 2007 current body style)			PR3114*
RAM				
2013	2500 (NO DRILL)		PR4440	
2003-2012	2500 & 3500 (NO DRILL)		PR3349	
2019-2020	1500 (5'8" bed, new body style) (NO DRILL) (does not fit Ram 1500 w/ factory air suspension)			PR3125*
2009-2019	1500 (5'7" & 6-1/2' bed, old body style)			PR3122*
2002-2008	1500 (NO DRILL)		PR3349	
1995-2002	(except '02 1500)	PR3340	PR3346	
FORD				
1999-2016	F250 & F350	PR3340	PR4426	
2015-2020	F150 (5'6" bed)			PR3123*
2004-2014	F150 (6-1/2' bed)		PR3361	
1997-2003	F150 (6-1/2' bed)	PR3340	PR3342	
2009-2014	F150 (5' 7" bed)			PR3119*
2004-2008	SuperCrew F-150 (5'6" bed)			PR3113*
2001-2003	SuperCrew F-150 (5'6" bed)			PR3111*
TOYOTA				
2007-2019	Tundra, Double Cab, Short Bed (6-1/2" bed) Universal Rails w/ Custom Mounting Brackets	PR4421		
2001-2006	Tundra, Standard Cab			PR3112*
2007-2019	Tundra, Crew Max, Super Short Bed (5-1/2" bed)			PR3118*

ALL THE ABOVE KITS FIT 6-1/2' SHORT BED TRUCKS, EXCEPT #3100 SUPERGLIDE WHICH IS DESIGNED FOR SUPER SHORT (5-1/2') BEDS ONLY.

\* TO DETERMINE CORRECT #3100 SUPERGLIDE TRUCK/TRAILER COMBINATIONS, CLICK HERE.

**UNIVERSAL KITS INCLUDE "bolt to the bed" Baserails, Universal "L" Brackets and Hardware**  
**SUPERRAIL KITS featuring Clean Bed Technology include totally removable SuperRails & Posts, Mounting Brackets & Hardware**  
**#3100 SUPERRAIL KITS featuring Clean Bed Technology include totally removable SuperRails & Posts, Mounting Brackets &**



1470 Vinci Ave  
Sacramento, CA. 95838  
(916) 992-9703  
(800) 400-5275

92020